

Job Name: \_\_\_\_\_ Date: \_\_\_\_\_

Door Mark: \_\_\_\_\_ Sheet#: \_\_\_\_\_ of \_\_\_\_\_

### GENERAL INFO

Door Material:  Hollow Metal  Wood Door (Wood Species/finish/Cut: \_\_\_\_\_)

*\*Always check top edge of door for any manufacturing labels.*

Door Thickness: 1-3/4" 1-3/8" Other \_\_\_\_\_ Hand (See below): \_\_\_\_\_

### DOOR OPTIONS

Fire Rating:  None  20min  45min  90min  3hour  Smoke

Lite Kit:  None  Vision Lite  Narrow Lite  Half Lite  Full Lite (Exposed Glass: \_\_\_\_\_ X \_\_\_\_\_)

Top of Door to exposed glass: \_\_\_\_\_ Lock Edge of Door to exposed glass: \_\_\_\_\_

Glass Thickness: \_\_\_\_\_ Glass type: \_\_\_\_\_ Lite Kit Material: \_\_\_\_\_ (wood or metal)

Louver:  None  12"x12"  12"x24"  24"x24"  Full Louver (Exposed Vents: \_\_\_\_\_ X \_\_\_\_\_)

Top of Door to exposed vents: \_\_\_\_\_ Lock Edge of Door to exposed vents: \_\_\_\_\_

Louver Material: \_\_\_\_\_ (Wood or Steel)

Lock prep:  2-1/8" Bore  Mortise Lock  Panic Device (Details: \_\_\_\_\_)

Lock Backset:  2-3/4"  2-3/8"  5"

*\*List lock details/model/function*

Hardware preps:  Deadbolt  Closer (Other: \_\_\_\_\_)

Peephole: \_\_\_\_\_ Hole Diameter: \_\_\_\_\_ Location: \_\_\_\_\_ (Ex 60" A.F.F.).

Notes: \_\_\_\_\_

*\*Make note if hardware is to be new or reused. Hardware finish. List any other hardware such as Thresholds, weatherstrip, stops, etc.*

### MEASUREMENTS

*\*Most often it is best to measure the frame so that a door can be made to fit the doorway, we will undersize the door to fit your frame properly. For measurements A & B take multiple measurements and use the smallest. For example measure the width of the frame at the top, in the middle near the lock, and then at the bottom.*

- \_\_\_\_\_ A <Inside of the frame width. (36")
- \_\_\_\_\_ B <Inside of the frame height. (84")
- \_\_\_\_\_ C <Actual door height. (83-1/8")
- \_\_\_\_\_ D <Height of the hinge prep. (4-1/2" or 5")
- \_\_\_\_\_ E <Top of frame to top of hinge.
- \_\_\_\_\_ F <Top of frame to top of hinge.
- \_\_\_\_\_ G <Top of frame to top of hinge.
- \_\_\_\_\_ H <Top of frame to top of hinge.
- \_\_\_\_\_ I <Top of frame to Centerline of Strike.
- \_\_\_\_\_ J <Height of Strike Prep. (4-7/8" or 2-3/4")
- \_\_\_\_\_ K <Top of frame to Centerline of DB Strike.
- \_\_\_\_\_ L <Height of DB Strike Prep. (2-1/4" or 3-1/2")

